




















## Precut Shapes - Printable Guide

Shape	Size (mm)	Application	Shape	Size (mm)	Application
	#01 2.54 x 6.35	All brands of flutes key foot.		#11 6.8 x 8.0	Bundy (and other) clarinet C#-G#.
	#02 2.50 x 6.0	Bundy (and other) clarinet F-C keys.		#12 16 x 9.0	Selmer (and other) Front F.
	#03 2.50 x 8.0	Bundy clarinet (and others) thumb ring, C trill, E-B lever (foot), F#-C# lever (foot).		#13 12.7 x 11.7	Bundy (and other) clarinet thumb rest.
	#04 2.50 x 10.0	Bundy (and other) clarinet F# trill, F# ring, B-F#.		#14 3.0	
	#05 2.0 x 4.5	Bundy (and other) clarinet Bb trill, F-C lever.		#15 4.0	
	#06 5 x 9.5	Bundy (and other) clarinet crowsfoot, lower bridge, G#.		#16 6.0	
	#07 5.5 x 11.6	Selmer sax long rod cradle, Yanigisawa sax body under RH feet.		#17 6.5	
	#08 3.0 x 9.5	Bundy (and other) clarinet aux Eb-Bb, most sax key feet, Yanigisawa sax G to bis.		#18 8.0	
	#09 5.0 x 4.0	Bundy clarinet (and others) side Bb, A, register.		#19 9.0	
	#10 4.8 x 5.6	Bundy (and other) clarinet upper bridge.			